

FREQUENCY AGILE F.C.C. COMPATIBLE TELEVISION MODULATOR

INSTRUCTION MANUAL

Phone: (209) 586-1022 (800) 545-1022 Fax: (209) 586-1026 E-Mail: salessupport@olsontech.com www.olsontech.com

SPECIFICATIONS

Output Frequency Range	. Selectable in .25MHz increments.
	7.00MHz, Ch. T7 to 547.25MHz, Ch. 78
Output Level	. +55dBmV min., 15.0 - 547.25MHz;
	+52dBmV min., 7.0MHz
Frequency Accuracy/Stability	. <±5KHz of selected channel frequency
Out-of-Band C/N Ratio	>80dB as measured in a 4.0MHz noise bandwidth.
Spurious Output	\geq 55dB down @ 55dBmV output, 15.00 to
	547.25MHz; ≥55dB down @ 52dBmV output, 7.0MHz
I.F. Output Frequency	Video 45.75MHz, audio 41.25MHz
Video IF Level	.+40dBmV
Video Carrier Level	. Adjustable downward by 10dB minimum.
Video Performance	Measured @ 80% modulation. Differential gain
	<6%. Differential phase <3°. Video input 1 volt
	p-p (75 Ω). 170 nSec predistortion, ± 40nSec.
Audio Intercarrier Stability	.<±1KHz
Audio Deviation	25KHz - 75 µsec pre-emphasis. Minimum 500mV
	p-p input.
Audio/Video Ratio	Adjustable from 12dB to 20dB below video carrier.
Front Panel Controls	Channel/F.C.C. offset, video/audio modulation,
	R.F. level and A/V ratio.
Front Panel Indicators	LED's for video/audio overmodulation.
Rear Panel Connectors	. 75 Ω type F: Video input, RF output, -20dB test
	point and video/audio IF loops. Terminal strip:
	600Ω balanced audio input. 3-wire power cord/USA plug.
Power Consumption	. 115 VAC @ 60Hz - 15 watts.
Fuse	0.5 amp Slo-blo
Size	1.75" H x 19" W x 8" D.

FREQUENCY AGILE - F.C.C. COMPATIBLE TELEVISION MODULATOR

1) INTRODUCTION

The Olson Technology OTM-3550-SW is a frequency agile F.C.C. compatible television modulator that will provide high level output, on any channel from 7.00MHz, Ch. T7 through 547.25MHz, Ch. 78, including all HRC and IRC output channels. All channels are selectable in 0.25MHz increments by front panel DIP switches. F.C.C. offsets of +12KHz and +25KHz are also selectable by front panel DIP switches.

The OTM-3550-SW uses SAW filtering for 60dB adjacent channel rejection. This unit also offers the unique Olson Technology feature of >80dB out-of-band carrier to noise ratio which allows virtually unlimited numbers of the OTM-3550-SW to be combined without the need for external band pass filters. The OTM-3550-SW is BTSC stereo compatible.

2) CHANNEL SELECTION

Remove the front panel plate marked "Output Channel Select" to expose the channel select and offset select DIP switches as shown in Figure #1.



Figure #1 FRONT PANEL DIP SWITCHES

- 1) Select the desired channel by use of the channel select switch and the code sheets.
- 2) Select the proper offset by use of the offset switch and the offset information on the next page.
- 3) The example above indicates channel 6 with 0KHz offset.

1 = Switch in UP Position

OFFSET SELECT INFORMATION

- 1) Channels 14 (A), 15 (B), 16 (C), 25 to 41 (L to EE) & 43 to 53 (GG to QQ) = 12.5KHz.
- 2) Channels 98 (A-2), 99 (A-1) & 42 (FF) = 25KHz.
- 3) All others = 0 KHz.

<u>Offset</u>	(3) Rightmost DIP Switches
0KHz	011
12.5KHz	101
25.0KHz	110

3) F.C.C. OFFSET FREQUENCIES

EIA CHANNEL	HISTORIC CHANNEL	F.C.C. OFFSET KHz	CHANNEL FREQUENCY INCL. OFFSET MHz
98	A-2	25.0	109.2750
99	A-1	25.0	115.2750
14	A	12.5	121.2625
15	В	12.5	127.2625
16	С	12.5	133.2625
25	L	12.5	229.2625
26	M	12.5	235.2625
27	N	12.5	241.2625
28	0	12.5	247.2625
29	Р	12.5	253.2625
30	Q	12.5	259.2625
31	R	12.5	265.2625
32	S	12.5	271.2625
33	т	12.5	277.2625
34	U	12.5	283.2625
35	V	12.5	289.2625
36	W	12.5	295.2625
37	AA	12.5	301.2625
38	BB	12.5	307.2625
39	CC	12.5	313.2625
40	DD	12.5	319.2625

EIA CHANNEL	HISTORIC CHANNEL	F.C.C. OFFSET KHz	CHANNEL FREQUENCY INCLUDING OFFSET MHz
41	EE	12.5	325.2625
42	FF	25.0	331.2750
43	GG	12.5	337.2625
44	НН	12.5	343.2625
45	II	12.5	349.2625
46	JJ	12.5	355.2625
47	KK	12.5	361.2625
48	LL	12.5	367.2625
49	MM	12.5	373.2625
50	NN	12.5	379.2625
51	00	12.5	385.2625
52	PP	12.5	391.2625
53	QQ	12.5	397.2625

F.C.C. OFFSET FREQUENCIES (Continued)

4) VIDEO MODULATION ADJUSTMENT

- A) Connect a video source of approximately 1V p-p to the video input connector (75 ohms input Z) on the rear panel. The video should be of a reasonably bright scene (commercials are usually excellent).
- B) The video overmodulation indicator LED may stay on for approximately one minute after the unit is first turned on. Wait for approximately one minute before adjusting the video modulation control and observing the LED.

Rotate the video modulation level adjust control slowly clockwise until the video overmodulation LED just turns on. <u>CAUTION</u>: If the modulation is set too high, compression or lack of contrast will occur during high intensity scenes.

5) AUDIO MODULATION ADJUSTMENT

- A) Connect an audio source of 500mV p-p (minimum) to the balanced audio input connector (600 ohms input Z) on the rear panel. The source should be typical of the program material to be carried.
- B) Rotate the audio modulation level adjust control slowly clockwise until the audio overmodulation LED just begins to blink. <u>CAUTION</u>: Overmodulation can result in severe distortion in some TV sets. Set this control at peak program levels.

6) RFAND AURAL CARRIER LEVEL ADJUSTMENT

- A) Using a field strength meter, set the video carrier to the desired level with the RF output level adjust control. It is suggested that the operating level of the OTM-3550-SW be not less than 4dB below the specified output level. If the output level must be lowered more than 4dB from the full specified output level, a fixed attenuator pad may be placed at the unit's output.
- B) Tune the field strength meter to the aural carrier (4.5MHz above the video carrier).
- C) Adjust the aural carrier level control to the desired level, typically 15dB below the video carrier. <u>CAUTION:</u> Reducing the visual/aural carrier ratio to less than 15dB can result in high out-of-band spurious signals in adjacent channels.

7) MISCELLANEOUS

- A) The OTM-3550-SW is BTSC stereo compatible. It is shipped in the "mono" mode. To use a composite BTSC baseband input signal the pre-emphasis must be defeated. Remove the top cover and move the internal jumper plug from W2 "PRE" to W2 "BY". This plug is located in the left front area of the circuit board.
- B) This unit is equipped with external video and audio I.F. loops. Each loop is connected with a short "F" type coax jumper. If either jumper is disconnected or lost, the unit will not perform properly.
- C) If a scrambling unit is utilized with the OTM-3550-SW, follow the instructions associated with the scrambler. The video I.F. output level is +40dBmV, and the audio carrier level is determined by the aural carrier level adjustment typically +22dBmV @ 15dB A/V ratio.
- D) This unit is equipped with a 0.5A slo-blo fuse. For continued safety and to maintain proper performance of the unit, please replace only with an equivalent fuse.
- E) A -20dB test point (type F connector) is provided in the rear panel.
- F) When installing the OTM-3550-SW in an equipment rack, it is best to leave an empty rack space above and below the unit to allow for optimum air circulation.

FREQUENCY MHz	EIA CHANNEL	HISTORIC CHANNEL	CHANNEL SELECT SW1 SW2
7.00		т7	11110101 10010
13.00		т8	1 1 1 0 0 0 1 1 1 0 0 1 0
19.00		Т9	1 1 1 1 1 0 1 1 1 0 0 1 0
25.00		T10	1 1 1 0 1 1 1 1 1 0 0 1 0
31.00		T11	11110000 01010
37.00		T12	11100100 01010
43.00		T13	1 1 1 1 1 1 0 0 0 1 0 1 0
55.25	2	2	0 0 0 0 1 1 1 0 0 1 0 1 0
61.25	3	3	0 0 0 1 0 0 0 1 0 1 0 1 0
67.25	4	4	0 0 0 0 0 1 0 1 0 1 0 1 0
77.25	5	5	0 0 0 1 0 0 1 1 0 1 0 1 0
83.25	6	6	0 0 0 0 0 1 1 1 0 1 0 1 0
91.25	95	A-5	0 0 0 0 0 0 0 0 1 1 0 1 0
97.25	96	A-4	0 0 0 1 1 0 0 0 1 1 0 1 0
103.25	97	A-3	0 0 0 0 1 1 0 0 1 1 0 1 0
109.25	98	A-2	0 0 0 1 0 0 1 0 1 1 0 1 0
115.25	99	A-1	0 0 0 0 0 1 1 0 1 1 0 1 0
121.25	14	A	0 0 0 1 1 1 1 0 1 1 0 1 0
127.25	15	В	0 0 0 0 1 0 0 1 1 1 0 1 0
133.25	16	С	0 0 0 1 0 1 0 1 1 0 1 0
139.25	17	D	0 0 0 0 0 0 1 1 1 0 1 0
145.25	18	E	0 0 0 1 1 0 1 1 1 0 1 0
151.25	19	F	0 0 0 0 1 1 1 1 1 0 1 0
157.25	20	G	0 0 0 1 0 0 0 0 0 0 1 1 0
163.25	21	H	0 0 0 0 1 0 0 0 0 1 1 0
169.25	22	I	0 0 0 1 1 1 0 0 0 0 1 1 0
175.25	7	7	00001010 00110
181.25	8	8	0 0 0 1 0 1 1 0 0 0 1 1 0
187.25	9	9	0 0 0 0 0 0 1 0 0 1 1 0
193.25	10	10	0 0 0 1 1 0 0 1 0 0 1 1 0

STANDARD TV CHANNEL CODES FOR MODULATOR

STANDARD TV CHANNEL CODES FOR MODULATOR (Continued)

FREQUENCY MHz	EIA CHANNEL	HISTORIC CHANNEL	CHANNEL SELECT SW1 SW2
199.25	11	11	0 0 0 0 1 1 0 1 0 0 1 1 0
205.25	12	12	0 0 0 1 0 0 1 1 0 0 1 1 0
211.25	13	13	0 0 0 0 0 1 1 1 0 0 1 1 0
217.25	23	J	0 0 0 1 1 1 1 1 0 0 1 1 0
223.25	24	K	0 0 0 0 1 0 0 0 1 0 1 1 0
229.25	25	L	0 0 0 1 0 1 0 0 1 0 1 1 0
235.25	26	М	0 0 0 0 0 1 0 1 1 0 1 1 0
241.25	27	N	0 0 0 1 1 0 1 0 1 1 0
247.25	28	0	0 0 0 0 1 1 1 0 1 0 1 1 0
253.25	29	Р	0 0 0 1 0 0 0 1 1 0 1 1 0
259.25	30	Q	0 0 0 0 0 1 0 1 1 0 1 1 0
265.25	31	R	0 0 0 1 1 1 0 1 1 0 1 1 0
271.25	32	S	0 0 0 0 1 0 1 1 1 0 1 1 0
277.25	33	Т	0 0 0 1 0 1 1 1 1 0 1 1 0
283.25	34	U	0 0 0 0 0 0 0 0 0 1 1 1 0
289.25	35	V	0 0 0 1 1 0 0 0 0 1 1 1 0
295.25	36	W	0 0 0 0 1 1 0 0 0 1 1 1 0
301.25	37	AA	0 0 0 1 0 0 1 0 0 1 1 1 0
307.25	38	BB	0 0 0 0 0 1 1 0 0 1 1 1 0
313.25	39	CC	0 0 0 1 1 1 1 0 0 1 1 1 0
319.25	40	DD	0 0 0 0 1 0 0 1 0 1 1 1 0
325.25	41	EE	0 0 0 1 0 1 0 1 0 1 1 1 0
331.25	42	FF	0 0 0 0 0 0 1 1 0 1 1 1 0
337.25	43	GG	0 0 0 1 1 0 1 1 0 1 1 1 0
343.25	44	HH	0 0 0 0 1 1 1 1 0 1 1 1 0
349.25	45	II	0 0 0 1 0 0 0 0 1 1 1 1 0
355.25	46	JJ	0 0 0 0 1 0 0 1 1 1 1 0
361.25	47	KK	0 0 0 1 1 1 0 0 1 1 1 1 0
367.25	48	$\mathbf{L}\mathbf{L}$	0 0 0 1 0 1 0 1 1 1 1 0
373.25	49	MM	0 0 0 1 0 1 1 0 1 1 1 1 0

STANDARD TV CHANNEL CODES FOR MODULATOR (Continued)

FREQUENCY MHz	EIA CHANNEL	HISTORIC CHANNEL	CHANNEL SELECT SW1 SW2
379.25	50	NN	0 0 0 0 0 0 0 1 1 1 1 1 0
385.25	51	00	0 0 0 1 1 0 0 1 1 1 1 1 0
391.25	52	PP	0 0 0 0 1 1 0 1 1 1 1 0
397.25	53	QQ	0 0 0 1 0 0 1 1 1 1 1 1 0
403.25	54	RR	0 0 0 0 0 1 1 1 1 1 1 1 0
409.25	55	SS	0 0 0 1 1 1 1 1 1 1 1 0
415.25	56	TT	0 0 0 0 1 0 0 0 0 0 0 1
421.25	57	UU	0 0 0 1 0 1 0 0 0 0 0 0 1
427.25	58	vv	0 0 0 0 0 1 0 0 0 0 1
433.25	59	WW	0 0 0 1 1 0 1 0 0 0 0 0 1
439.25	60	XX	0 0 0 0 1 1 1 0 0 0 0 0 1
445.25	61	YY	0 0 0 1 0 0 0 1 0 0 0 0 1
451.25	62	ZZ	0 0 0 0 0 1 0 1 0 0 0 0 1
457.25	63	63	0 0 0 1 1 1 0 1 0 0 0 0 1
463.25	64	64	0 0 0 0 1 0 1 1 0 0 0 0 1
469.25	65	65	0 0 0 1 0 1 1 1 0 0 0 0 1
475.25	66	66	0 0 0 0 0 0 0 0 1 0 0 0 1
481.25	67	67	0 0 0 1 1 0 0 0 1 0 0 0 1
487.25	68	68	0 0 0 0 1 1 0 0 1 0 0 0 1
493.25	69	69	0 0 0 1 0 0 1 0 1 0 0 0 1
499.25	70	70	0 0 0 0 0 1 1 0 1 0 0 1
505.25	71	71	00011110 10001
511.25	72	72	0 0 0 0 1 0 0 1 1 0 0 0 1
517.25	73	73	0 0 0 1 0 1 0 1 1 0 0 0 1
523.25	74	74	0 0 0 0 0 0 1 1 1 0 0 0 1
529.25	75	75	0 0 0 1 1 0 1 1 1 0 0 0 1
535.25	76	76	0 0 0 0 1 1 1 1 1 0 0 0 1
541.25	77	77	00010000 01001
547.25	78	78	0 0 0 0 1 0 0 0 1 0 0 1

See end of manual for switch setting calculations for other frequencies.

FREQUENCY MHz	EIA CHANNEL	HISTORIC CHANNEL	CHANNEL SELECT SW1 SW2
54.00	2	2	11010110 01010
60.00	3	3	1 1 0 0 0 0 1 0 1 0 1 0
66.00	4	4	11011001 01010
72.00	5	5	11001101 01010
78.00	6	6	1 1 0 1 0 0 1 1 0 1 0 1 0
84.00		A-6	1 1 0 0 0 1 1 1 0 1 0 1 0
90.00	95	A-5	11011111 01010
96.00	96	A-4	11001000 11010
102.00	97	A-3	11010100 11010
108.00	98	A-2	11000010 11010
114.00	99	A-1	11011010 11010
120.00	14	A	1 1 0 0 1 1 1 0 1 1 0 1 0
126.00	15	В	11010001 11010
132.00	16	С	1 1 0 0 0 1 0 1 1 1 0 1 0
138.00	17	D	1 1 0 1 1 1 0 1 1 1 0 1 0
144.00	18	E	11001011 11010
150.00	19	F	11010111 11010
156.00	20	G	1100000000110
162.00	21	Н	1 1 0 1 1 0 0 0 0 0 1 1 0
168.00	22	I	11001100 00110
174.00	7	7	11010010 00110
180.00	8	8	11000110 00110
186.00	9	9	1 1 0 1 1 1 1 0 0 0 1 1 0
192.00	10	10	1 1 0 0 1 0 0 1 0 0 1 1 0
198.00	11	11	11010101 00110
204.00	12	12	1 1 0 0 0 0 1 1 0 0 1 1 0
210.00	13	13	1 1 0 1 1 0 1 1 0 0 1 1 0
216.00	23	J	1 1 0 0 1 1 1 1 0 0 1 1 0
222.00	24	K	1 1 0 1 0 0 0 0 1 0 1 1 0
228.00	25	L	11000100 10110

HRC CHANNELS CODES FOR MODULATOR

FREQUENCY MHz	EIA CHANNEL	HISTORIC CHANNEL	CHANNEL SELECT SW1 SW2
234.00	26	М	1 1 0 1 1 1 0 0 1 0 1 1 0
240.00	27	N	1 1 0 0 1 0 1 0 1 1 0 1 1 0
246.00	28	0	1 1 0 1 0 1 1 0 1 1 0 1 1 0
252.00	29	P	1 1 0 0 0 0 0 1 1 0 1 1 0
258.00	30	Q	1 1 0 1 1 0 0 1 1 0 1 1 0
264.00	31	R	11001101 10110
270.00	32	S	11010011 10110
276.00	33	т	11000111 10110
282.00	34	U	1 1 0 1 1 1 1 1 1 0 1 1 0
288.00	35	V	11001000 01110
294.00	36	W	11010100 01110
300.00	37	AA	11000010 01110
306.00	38	BB	1 1 0 1 1 0 1 0 0 1 1 1 0
312.00	39	CC	1 1 0 0 1 1 1 0 0 1 1 1 0
318.00	40	DD	1 1 0 1 0 0 0 1 0 1 1 1 0
324.00	41	EE	1 1 0 0 0 1 0 1 0 1 1 1 0
330.00	42	FF	1 1 0 1 1 1 0 1 0 1 1 1 0
336.00	43	GG	11001011 01110
342.00	44	HH	11010111 01110
348.00	45	II	11000000 11110
354.00	46	JJ	11011000 11110
360.00	47	KK	11001100 11110
366.00	48	LL	11010010 11110
372.00	49	MM	1 1 0 0 0 1 1 0 1 1 1 1 0
378.00	50	NN	1 1 0 1 1 1 1 0 1 1 1 1 0
384.00	51	00	1 1 0 0 1 0 0 1 1 1 1 1 0
390.00	52	PP	11010101 11110
396.00	53	QQ	1 1 0 0 0 0 1 1 1 1 1 1 0
402.00	54	RR	1 1 0 1 1 0 1 1 1 1 1 1 0
408.00	55	SS	11001111 11110

HRC CHANNELS CODES FOR MODULATOR (Continued)

FREQUENCY MHz	EIA CHANNEL	HISTORIC CHANNEL	CHANNEL SELECT SW1 SW2
414.00	56	TT	1 1 0 1 0 0 0 0 0 0 0 1
420.00	57	ບບ	11000100 00001
426.00	58	vv	1 1 0 1 1 1 0 0 0 0 0 1
432.00	59	WW	11001010 00001
438.00	60	XX	1 1 0 1 0 1 1 0 0 0 0 0 1
444.00	61	YY	1100001 00001
450.00	62	ZZ	1 1 0 1 1 0 0 1 0 0 0 0 1
456.00	63	63	11001101 00001
462.00	64	64	11010011 00001
468.00	65	65	11000111 00001
474.00	66	66	1 1 0 1 1 1 1 1 0 0 0 0 1
480.00	67	67	1 1 0 0 1 0 0 0 1 0 0 0 1
486.00	68	68	1 1 0 1 0 1 0 0 1 0 0 0 1
492.00	69	69	11000010 10001
498.00	70	70	1 1 0 1 1 0 1 0 1 0 0 1
504.00	71	71	11001110 10001
510.00	72	72	1 1 0 1 0 0 0 1 1 0 0 0 1
516.00	73	73	11000101 10001
522.00	74	74	11011101 10001
528.00	75	75	11001011 10001
534.00	76	76	1 1 0 1 0 1 1 1 1 0 0 0 1
540.00	77	77	1 1 0 0 0 0 0 0 1 0 0 1
546.00	78	78	1 1 0 1 1 0 0 0 0 1 0 0 1

HRC CHANNELS CODES FOR MODULATOR (Continued)

MODULATOR SWITCH SETTING CALCULATION THE OTM-3550-SW IS FACTORY PRESET WITH 250KHz STEP SIZE.

To calculate the switch settings for a given output frequency use the following procedure:

1) Calculate the number "N" required for step 2, below.

Use this formula:

N = <u>OUTPUT FREQUENCY</u> + <u>2ND IF FREQUENCY</u> STEP SIZE (IN MHZ)

NOTE: 2nd IF FREQUENCY FOR ALL NTSC = 612.75

2) Convert the number "N" to reversed binary as required to set the unit DIP switches. This binary number represents the switch settings with 1 = UP and 0 = DOWN.

Use this chart to convert the number "N" to reversed binary:

- 3) Set the DIP switches using the binary number from above.
- 4) Determine what FCC offset, if any, is required and set the offset select switch positions correctly.

EXAMPLE OF SWITCH SETTING CALCULATION

Required: Settings for channel 7 (175.250 MHz).

1) $\frac{175.25 + 612.75}{0.25} = \frac{788}{0.25} = 3152$

- 2) Convert the number "N" (3152) to reversed binary.
 - A) Consult the chart above and locate the largest number less than or equal to 3152. This would be "2048". Place a "1" below this number.

Subtract this number from the original number to obtain the remaining number to use in the next step. This would be "1077" (3152 - 2048 = 1104).

B) Consult the chart above and locate the largest number less than or equal to 1104. This would be "1024". Place a "1" below this number.

Subtract this number from the previous number to obtain the remaining number to use in the next step. This would be "80" (1104 - 1024 = 80).

C) Consult the chart above and locate the largest number less than or equal to 80. This would be "64". Place a "1" below this number.

Subtract this number from the previous number to obtain the remaining number to use in the next step. This would be "16" (80 - 64 = 16).

- D) Continue in this fashion until the remaining number is reduced to "0". Note that the remaining number must be reduced to <u>exactly</u> 0 by the above process.
- E) Place a "0" below all other decimal numbers in the chart. The resulting reversed binary number is $0\ 0\ 0\ 0\ 1\ 0\ 1\ 0\ 0\ 0\ 1\ 1\ 0.$

3) Set the DIP switches using the binary number from above.

A) Set the unit DIP switches left-to-right. Set them DOWN for a binary "0" and UP for a binary "1".

4) Determine what FCC offset, if any, is required and set the offset select switch positions correctly.

- A) Determine if any offset is required from the offset select section of this manual. No offset is required for channel 7 (175.250 MHz).
- B) Set the last three DIP switch positions using the information from the offset select section of this manual. This would be 0 1 1.